



Check your specific build:  
 If there is free space behind these, drill 5.5mm  
 through holes and use M5 bolts and nuts,  
 otherwise use woodscrews

for page alignment if printed on A4

Dept.	Technical reference	Created by	Approved by	Rev.	Date of issue	Sheet
		Koenich				1/1
	Document type	14.06.2021	Document status	DWG No.		
	Title	Wooden Z-Plate - V3V28				